

User Guide for Glow Gear 12 foot Inflatable Target structure

1. Inflation – Use either the 2.5” diameter valve with Black or Red cap –OR- the small, grey “Boston” valve with the twist top. Note on Original targets – **do not use valve with large Red cap – it has been sealed permanently and will not open! Again, use the smaller 2.5” diameter valve with black or red cap.**



2. Inflation method – either a leaf blower or shop vac is recommended to inflate the target. Gas or electric Leaf blower is preferred. Target should be inflated at the location on the range or green where it will be used. Inflate to a firm pressure – do not over-inflate. Targets may lose air over a few hours or with temperature change from hot to cold at night. Before the start of an event – check inflation level and top off, if needed. Targets lights will flash with targets even with low pressure.



3. Inflate target at location of use. Position the target with valves at right angles to the front of the range and away from golf ball hits. To move the target, position 1 person on each side of the target and lift the target by D rings or from the bottom, not recommended to drag across the ground as it may cause puncture or tear in the target.

4. **Use Metal D rings to stake down with bungee cord or rope and metal stakes. For water, tie mooring and/or anchoring lines to D rings.**
5. **Target light** – see the Light programming guide for color changes. When you are ready to set up the target, turn the light on as the switch on the side and place inside the zipper pouch
 - a. Use on the **ground** - insert face up inside the zipper pouch on the bottom of the target.
 - b. **Water Use** – insert in the zipper pocket that is on top of the target and out of the water.
Note: target light is water resistant but not waterproof – **it is recommended to place the target light in a 2 gallon Ziploc or re-closeable clear plastic bag to protect the light.**
 - c. **Rain or weather** – place the target light in a 2 gallon Ziploc bag to protect from water damage.
6. **Target deflation and pack up** – Remove the light from the zipper pocket. To deflate use the intake side of the blower (with an extension tube) to suck air out of the target for fastest deflation time and best storage



7. **Folding Target** – after full deflation - position the target so the valves are lined up at the ends before folding inward. Then make 3 folds from each side to create a long length.

